



## Adjustable Wrench Instruction

1. Clamp the opposite side or diagonal of the nut for quick and continuous work.
2. For round nut, adjust the width between upper teeth 1-2mm less than the diameter of the nut.
3. Fit most shapes of nuts and bolts.

**Caution:** Do not use the wrench as a hammer.



**GUARANTEED:** Product warranted to be free from defects in material and workmanship unless caused by abuse, misuse or alteration. Warranty is limited to the replacement and/or repair of the product free of charge.

Distributed by: **Fox & Gunn Ltd,**  
**Auckland, New Zealand**